




# NOvA Module

## End Caps & Manifolds



1. Threading: Time & Motion Studies
2. Attaching Manifolds to Scalloped Extrusions
3. Avoiding 2 Styles of Extrusions



# Vacuum Puck



---

*Pull fiber down a 16 m extrusion cell  
using a vacuum*

- 10 sec: Attach fiber to puck
- 10 sec: Pull puck down extrusion
- 10 sec: Detach puck from fiber



# Fiber Threading Time & Motion




## Changes on connector since May 2005:

- Dual holes changed to slots (design intent)
- Holes were beveled at the back

## Threading Technicians:

- 1- Undergrad Student;  
1 Grad Student
- 1 hour training






# T&M: Lessons Learned




- Table height is ergonomically awful
- Bottom fiber raceway is installed too low
- Handedness is backwards





# T&M: Results

- Undergrad: 29 min
- Grad: 25 min





*We met our 30 min goal;  
expect substantial improvement!*



# Manifold Scallop Adapter




Integral fiber fingers



Straight slots for  
extruded parts




# Sealing Scallops





# Reinforcing Vertical End Extrusions








# Summary



- 
- Vacuum puck works well for stringing fibers
  - 30 min threading time achieved; further improvement expected
  - “Scallop adapter” enables using extruded manifold parts on scalloped extrusions (extrusion tolerances are an issue)
  - We suggest using only one style of extrusion



# Manifold Concept





# Manifold Overflow Tank

