




Light, Noise, APDs, and Electronics

Leon Mualem
University of Minnesota
October 2, 2004



Light

- Tested 0.8mm fibers with loops of fiber 2.8cm in diameter. At least seven loops of fiber, equivalent to 14 “bottom end” loops.
- Periodically tested for attenuation
- First point of graphs is before looping.
- Initially ~5% change indicates 99.5% transmission
- Mostly this test underscores lessons learned from MINOS
- --Be careful handling fibers.
- Don't have fibers come out of a rigid connection without strain relief
- Shows upper limit of attenuation in loop ~1%






Current Activities

- Measure APD properties
 - Noise vs. T
 - Gain
 - Signal response
- No surprises
- Measure Noise in 3 more boards
 - Noise decreased to $\sim 310e^-$ with new boards
- Measure Detector Properties:
 - Light output vs. Position (See KH VS talk)



New MASDA Prototype Board

- Improved noise performance
- Experience of version 1 incorporated:
 - Low noise voltage regulator
 - designed in additional filtering/bypassing





Improvements to Prototype boards


- **Firmware re-written with two major corrections**
 - **Installed a triggered mode to work with external coincidence trigger – Air shower particles, or pulser**
 - **Reduced the noise by about 10% with a couple of fixes**
 - **Lengthen hold time for the “before” sample ~5%**
 - **Add multiple samples of MASDA analog output**
 - **Effectively averages out noise in the analog output to reduce noise by about 5%**
 - **Version 2 board reduced input capacitance (trace length)**
 - **Noise level at operating point of APD: $M=100, T=-15^{\circ}\text{C}$ reduced to $315e^{-}$ from 360 reported previously.**



Noise vs. T for 4 new boards

Four boards in use:

Noise = $310e^-$ at
 $T = -15^\circ\text{C}$
 $M = 100$






Noise vs. T for 4 new boards (Closer look)


Four boards in use:

Noise = $310e^-$ at
 $T = -15^\circ\text{C}$
 $M=100$






Light Injection Signals





Light Injection Signal





Triggered Scintillator Tracker



- Provides realistic signals from scintillator/fiber strips
- 2 trigger arrays:
 - 8-wide x 4-thick with
 - standard PMT readout
 - NIM logic generates coincidences
- 1 scintillator test array:
 - 4-wide x 8 thick
 - APD readout






Triggered Mode Signals Search for Tracks

- Use entire upper trigger array.
- Use 2 columns of lower trigger array.
- Generate coincidence gate from PMT signals and the usual NIM Discriminator and logic modules.






Track from APD287





Shower with APD287

1600 pe total, ~ 80 MIPS, 150 MeV





Status Summary

- Several Working APD readout prototype boards
- 1 working board at UMN
- Currently 3 “in the wild”
 - 2 at IU, 1 at Caltech
- APD cooler boxes coming for these boards, O(weeks)
- More APDs on hand
- Waiting on MASDAs for rest of the prototype boards.