

Status of NOvA

Luke A. Corwin

Indiana University


Advances in Neutrino Technology

Philadelphia, PA - 2011 Oct. 10



Outline


- Brief Experimental Overview
- Scintillator
- PVC Extrusions
- Avalanche Photodiodes (APDs)
- Schedule



From Fermilab Visual Media Services: <http://www-visualmedia.fnal.gov/>, Image No. 11-0203-06D


ANL, Athens, Caltech, Institute of Physics of the Czech Republic, Charles University, Czech Technical University, FNAL, Harvard, Indiana, Iowa State, Lebedev, Michigan State, Minnesota/Duluth, Minnesota/Twin Cities, INR Moscow, South Carolina, SMU, Stanford, Tennessee, Texas/Austin, Tufts, Virginia, WSU, William and Mary

NOvA Experiment Overview




Near Detector


- 220 tons
- Will be placed in a new cavern in attached to the current MINOS cavern
- Characterize beam before oscillations



http://www-nova.fnal.gov/plots_and_figures/015_Detector_Overview/020-near-detector.png




Far Detector Building



Near Detector On the Surface (NDOS)



- **Prototype** built to the original design of the near detector
- Instrumented, operational and taking data
- Results
 - Taught us many lessons
 - Enabled us to correct many bugs and flaws
 - Several design and procedure change

From Fermilab Visual Media
Services: <http://www-visualmedia.fnal.gov/>,
Image No. 11-0124-13D




Detector Elements

- Cells with liquid scintillator grouped into alternating planes



http://www-visualmedia.fnal.gov/VMS_Site/gallery/stillphotos/2010/0100/10-0127-02D.jpg



Our Scintillator Recipe

Liquid Scintillator

94.91% food grade mineral oil

4.98% pseudocumene (scintillant)

0.110% parts PPO (powder, wave shifter)

0.00153% bis-MSB (powder, wave shifter)


0.0010% Stadis-425 (anti-static)

0.0010% Vitamin E (antioxidant)

1. Mix PPO, bis-MSB, Stadis-425, and Vitamin E into pseudocumene to produce fluor blend.

2. Mix fluor blend into mineral oil to produce NOvA liquid scintillator

Mixing The Scintillator



Have enough of everything except mineral oil and pseudocumene for 18kt far detector


Hired private contractor (Renkert Oil) to deliver mineral oil and mix ingredients



We currently have 300,000 gallons of oil in the tank.


Scintillator Quality Control

- Light Yield
 - Use radioactive sources to verify sufficient scintillator light
- Clarity tested using a commercial tintometer
- Verify correct chemical composition.
 - Done at Indiana Univ. Chemistry Dept.




Module Assembly

- Many pieces must be brought together to form an active detector module
- Cell interiors must be very reflective so scintillation light is not lost.




Manifold Issues

- Manifolds have developed cracks (22%)
 - Splinted the NDOs manifolds
 - Redesigned manifolds to remove stress points for near and far detectors



PVC Extrusions




- PVC extruded through die to form 15m extrusions
- ~24,000 required for Far Detector.
- Currently have ~2300 useable modules in hand.

PVC Reflectivity Issues

- We require predicted light yield to the APD to be $>14.6\%$ of a perfect reflector.
 - Achieved using TiO_2 in PVC, which is produced in two forms: rutile and anatase.
- Low reflectivity in some batches correlated with high fraction of rutile
 - Requested $<2\%$ rutile contamination, and so far that is what we have received.


PVC knitting issues

- PVC not “knitting” well when extruded from die
 - Ongoing iterations with manufacturer greatly improving results
 - No voids found in extrusions, so they are still useable




Extrusion samples are often cracked in QC testing, revealing smooth regions in the cross-section, such as the central region in this example, that are not well knitted.

Light Chain



Scintillation light travels along wavelength shifting fibers to end of manifold





Light detected in by avalanche photodiodes (APDs) that are sealed, cooled (to -15°C) and mated to the detector data acquisition system.




APD Noise Issues

- We have received a total of ~420 APDs for the NDOS
 - ~150 of them are still working
- Failure modes
 - Dirt and oil
 - Corrosion
 - Contact with fibers
 - Water leaks (leading to ice formation when cooled)
 - Installation Errors
 - Possibly unknown modes



Preserving and Redistributing APDs

- Running remaining APDs without cooling to preserve them
- Have begun be rearranging surviving APDs on the NDOS to collect highest quality data possible.




APD Potential Solutions

- “Cabel-ectomy”
 - Remove cable from noisiest pixel
 - Sometimes successful in reducing noise on neighboring pixels
- Coated APDs
 - Did not order APDs with coating because the standard coatings produced optical cross-talk
 - In discussions with manufacturer to produce APDs with protective coatings that will avoid cross-talk
 - Testing coatings of our own (silicone and parylene) on APDs on NDOS
- Attempting to clean/repair some of the non-functioning APDs





First Data!


**NOvA - FNAL E929**

Run: 10893/8

Event: 314724

UTC Tue Dec 21, 2010
11:48:18.997623872

First Data!




NOvA - FNAL E929

Run: 10893/8


Event: 314724

UTC Tue Dec 21, 2010

11:48:18.997623872



*Season's greetings
from the
NOvA collaboration*






A cosmic ray shower

Our first neutrino




Finding the Beams



Schedule

- Tevatron shutdown on Sep. 30, 2011
- First large scale fluor blend Oct. 12
- FD construction at Ash River site begins Jan. 2012
- FD finished in early 2014
- Accelerator shutdown Mar. 2012
- NOvA beam turns on Feb. 2013
- ND cavern excavation during accelerator shutdown





Backup

Far Detector

- 14,000 - 18,000 tons
- Will detect oscillated beam
- Largest object ever built of plastic



Quality Control




- Light Yield
 - Use radioactive sources to verify sufficient scintillator light
- Clarity (15 m long far detector cells)
 - Use a “tintometer”
 - Maintaining cleanliness critical at every stage!
- Chemistry
 - Verify correct chemical composition.



This is what we found when we looked inside of one of the fluor blending totes for the NDOS. The green substance was not identified (my guess was Mountain Dew). It was thoroughly cleaned by the blending company before any scintillator components were added.




Neutrino Interactions

- Like the wind, you can't see neutrinos, but you can see their effects.
- Simulated events at right



Off-axis

- Baseline (L) and E selected to maximize oscillations



Filling



- NDOS is filled with high-quality scintillator
- Pumping and piping systems being developed for Far Detector
- 6 tankers per week to Far Detector planned
- ~3,000,000 gallons



The NuMI Beam

- Small Cross section \Rightarrow we need large number of neutrinos \Rightarrow we need an intense beam

